

innovation in irrigation™

NELSON**1/2 PVC-4, 1/2 PVC-5, 3/4 PVC-5
ROTATOR® PVC STAKE ASSEMBLIES****ASSEMBLY INSTRUCTIONS:****STEP 1**

Cut PVC pipe to a desired stake length.

**STEP 2**

Drill a hole in the PVC Stake using a simple fixture and drill press. Use a standard drill bit (3/8" or 7/16") and locate the hole such that it will be 1/2" below soil level after the stake is installed in the ground.

**STEP 3**

Thread tubing through the hole of the PVC Stake.

**STEP 4**

Place the Stake Adapter (either #11258, #11271, or #11429) in hot water to warm. Use pliers or a large spoon to remove the adapters from the hot water. Push adapter onto tubing immediately after removing it from the hot water. **The tubing must be pushed into the adapter until it is completely flush with the top of the adapter.** Slide the tubing into the pipe and fit the adapter over the PVC pipe. **When assembling the LTO #9305, or #10080 place in hot water before pushing onto the the tubing.**

**OPTIONS:****1/2" PVC-4****1/2" PVC-5**

#11271
Adapter

#10080
LTO

3/4" PVC-5

#9305
LTO

WARRANTY AND DISCLAIMER: Nelson PVC Stake Assemblies are warranted for one year from the date of original sale to be free of defective material and workmanship when used within the working specifications for which the products were designed and under normal use and service. The manufacturer assumes no responsibility for installation, removal or unauthorized repair of defective parts and the manufacturer will not be liable for any crop or other consequential damages resulting from any defects or breach of warranty. **THIS WARRANTY IS EXPRESSLY IN LIEU OF ALL OTHER WARRANTIES, EXPRESS OR IMPLIED, INCLUDING THE WARRANTIES OF MERCHANTABILITY AND FITNESS FOR PARTICULAR PURPOSES AND OF ALL OTHER OBLIGATIONS OR LIABILITIES OF MANUFACTURER.** No agent, employee or representative of the manufacturer has authority to waive, alter or add to the provisions of this warranty nor to make any representations or warranty not contained herein.