




New! 3030 Pivot Sprinklers

3NV NOZZLE SYSTEM & 3030 SPRINKLER BODIES



PUSH & TURN TO CHANGE MODES

To install, point arrow to “IN” then push and turn clockwise to engage. To irrigate, point arrow to “ON” and **make sure nozzle clicks into place**. To shut off, point arrow to “OFF”*. While nozzle is in “OFF” position, use inspection port in 3030 body to check for obstruction. Nozzle flush occurs when the arrow points to “FLUSH”. Line flush occurs when the arrow points to “LINE FLUSH”. At this point, the nozzle is against the stop.

***IMPORTANT! DO NOT LEAVE IN “OFF” POSITION IN FREEZING CONDITIONS.**

Introducing the new 4-function 3NV Nozzle.

CONNECTION



3NV NOZZLE

3NV NOZZLE

#12035-0xx*

*xx — use same number system as 3TN nozzles

EVEN NOZZLES ROUND

ODD NOZZLES SCALLOPED

- ▶ Quick-change between four functions
- ▶ Covers complete nozzle range
- ▶ Same color-codes as 3TN but odd-size nozzles have scalloped edge
- ▶ Precision accuracy

3030 BODY

<p>ROTATOR®/ SPINNER BODY</p> <p>R3030 / S3030 #12034</p>	<p>ACCELERATOR/ SPRAYHEAD BODY</p> <p>A3030 / D3030 #12346</p>	<p>UNIVERSAL BODY</p> <p>U3030 #12381</p>	<p>ORBITOR BODY</p> <p>O3030</p>	<p>Orbitor plate, weight or plastic cover are fully assembled with the O3030 body.</p> <p>With Weight</p> <ul style="list-style-type: none"> #12317-101 black #12317-102 blue #12317-103 purple <p>With Plastic Cover</p> <ul style="list-style-type: none"> #12317-301 black #12317-302 blue #12317-303 purple
--	---	--	----------------------------------	---